FULL LOAD AMPERAGE TESTING

1. **This procedure should only be performed by a qualified electrician.**
2. Turn system off.
3. Open top door of Filter/Separator. Ensure door stays open while performing test.
4. Open Disconnect box
5. Bypass door interlock and turn power to system on.
6. Start system using Start push button
7. Allow system to come to full speed.
8. With a amperage clamp, measure amperage of each phase inside of the disconnect box.
9. Note reading for eash phase:

   P1_____ P2_____ P3_____

10. Stop system using Stop push button.
11. Return Disconnect to normal operation.
12. Close Separator door.

AUTOVAC Industrial Vacuum & Air systems
888-628-8682
www.autovacinc.com
sales@autovacinc.com

Product Data

FULL LOAD AMPERAGE TESTING

C010-0011